

Script “copysettings”



Description:

The script "copysettings.py" allows a user to copy the measurement settings of one signalshark task to another.



When the script is executed, a list of parameters including attenuation, RBW, center frequency, frequency span, and measurement time of the selected task on the signalshark device are provided in a checklist. The user can select one or more parameters. Once the parameters are selected, another dialog appears asking the user for a destination task to apply the settings to. After the settings have been applied, a completion dialog appears to notify the user.

Procedure

1. Select a task from all the active tasks on SignalShark from which the settings need to be copied.
2. Then open the Narda Script Launcher application and select the "nsltools" tab.
3. Select the script "Copy Settings".



6. The next dialog lists all the active tasks on the signalshark device. Select a destination task from the drop down menu and press "Ok".



Narda Safety Test Solutions GmbH
Sandwiesenstrasse 7
72793 Pfullingen, Germany
Phone +49 7121 97 32 0
info@narda-sts.com

www.narda-sts.com

Narda Safety Test Solutions
North America Representative Office
435 Moreland Road
Hauppauge, NY 11788, USA
Phone +1 631 231 1700
info@narda-sts.com

Narda Safety Test Solutions GmbH
Beijing Representative Office
Xiyuan Hotel, No. 1 Sanlihe Road, Haidian
100044 Beijing, China
Phone +86 10 6830 5870
support@narda-sts.cn

® Names and Logo are registered trademarks of Narda Safety Test Solutions GmbH – Trade names are trademarks of the owners.