

## Installing the USB driver and connecting for the first time

A USB driver for the USB connection to the IDA, NRA or SRM instrument is installed on the PC during installation of PC software (Tools). **Do not connect** the instrument to the PC via USB cable before you have installed the PC software. Please follow the steps below:

- 1) Start the installation of IDA/NRA/SRM Tools.
- 2) During installation the following message appears:



The reason for this is that the driver has not been subjected to the "Windows Logo" test routine offered by Microsoft. It has, however, been comprehensively tested and is perfectly safe to use.

- 3) Click on "Continue Anyway".
- 4) When installation is finished, connect the instrument to a USB port on the PC using the USB cable supplied.
- 5) Switch on the instrument.
- 6) The message "Found New Hardware" is displayed and the "Found New Hardware Wizard" opens.



Select "No, not this time" and click on "Next".

- 7) In the next screen



select "Install the software automatically (Recommended)" and click on "Next".

- 8) The "Windows Logo" test message is displayed again:



Click on "Continue Anyway".

- 9) The USB driver will then be installed. After installation is successfully completed, the following message appears:

